ARK ROCKET

TAURUS JUKEBOX

# Quick Unboxing Guide

## 01

### Locate Power Adapter & Cables

The **power adapter** is packed in a white box at the bottom of the packaging, along the edge of the protective foam.

The **connection cables** are in the accessory bag, also at the bottom of the packaging.

## 02

### Powering On

Press the **red power button** on the left to turn on the jukebox.

Press the **lighting button** on the right to activate the lighting system.

## 03

### Waking Up the Media Center

Press the **Standby** button to wake up the media center.

## 04

### Switching Playback Modes

Press the **Mode** button to switch between playback modes.

| | |
|---|---|
| **PH** | Phono (vinyl) mode |
| **BT** | Bluetooth input: connect your phone or other device |
| **— —** | CD mode (blinking) |

**Important:** The CD compartment door can only be opened when the unit is in CD mode.


WARRANTY & SUPPORT

**For warranty, technical support, or to find parts, please feel free to contact us.**

WEB
arkrocket.com/support

EMAIL
support@arkrocket.com


Scan for support & replacement parts